

Ultra-delicate microfiber cloth

A reliable solution for electronics and optics care. Our ultra-delicate microfiber cloth (15 × 18 cm) effectively removes greasy smudges and fingerprints from LCD screens, eyeglasses, lenses and camera optics — without streaks or scratches. Crafted from high-quality, durable, ultra-fine fibers (80% polyester, 20% polyamide), it delivers excellent absorbency and cleaning performance. Suitable for dry use, with water or alongside dedicated cleaning agents. Its compact size makes it perfect for use at home, in the office, or while traveling.

Product features:

- ✓ high-quality material,
- ✓ versatile applications,
- ✓ streak-free and scratch-free cleaning,
- ✓ compact size,
- ✓ easy to maintain in perfect condition.

Applications:

- ✓ laptops, monitors, computer cases,
- ✓ keyboards, mice, printers, scanners,
- ✓ phones, smartphones,
- ✓ glasses, camera lenses and other delicate optical devices.



Physicochemical properties

Color	Blue
Dimensions	15 x 18 cm
Weight	200 g/m ²
Composition	80% polyester, 20% polyamide
Shelf life	Unlimited



Compatibility:

The ultra-delicate microfiber cloth is safe for screens, glass surfaces, plastics and delicate electronic components, ensuring effective cleaning without the risk of scratches.

Application method	
Dry cleaning	Yes
Wet cleaning	Yes
With preparations	Yes

Usage instructions:

For daily cleaning, gently wipe the surface with a dry cloth to remove dust and light dirt. For more persistent stains, dampen the cloth with clean water or use dedicated cleaning solutions:

- ✓ **Plastic cleaner:** Ideal for cleaning computer cases, keyboards and other plastic components. Spray the cleaner onto the cloth and gently wipe the dirty area to restore shine and cleanliness.
- ✓ **Glass cleaner:** Recommended for monitors, screens and glass surfaces. Apply a small amount of cleaner to the cloth to remove smudges and dirt, achieving a crystal-clear finish.
- ✓ **LCD/TFT cleaner:** Specially formulated for delicate screens, ensuring safe and effective cleaning. Apply the cleaner to the cloth and gently wipe the screen, avoiding excessive pressure.

After cleaning, ensure all surfaces are dry. To prepare the cloth for reuse, rinse it with warm water or machine wash it at max 30°C. Avoid using bleach, chlorine or fabric softeners to maintain its absorbency and durability. The microfiber cloth is reusable, making it a practical and eco-friendly solution. For cleaning delicate surfaces such as optics (glasses, camera lenses), add a small amount of mild detergent, such as dish soap or a microfiber-specific washing agent, when rinsing. Gently rub the cloth, paying special attention to greasy spots, to effectively remove dirt. Finally, rinse the cloth thoroughly under running water until all detergent residue is gone.

If the cloth is used for cleaning delicate surfaces such as optics (glasses, camera lenses), we recommend adding a small amount of mild detergent during rinsing, for example dishwashing liquid or a product dedicated to washing microfiber. Gently rub the cloth, paying special attention to areas with greasy stains to effectively remove dirt. Finally, rinse the cloth thoroughly under running water until all detergent residues are completely removed.

Package

Blister pack

1 pcs. (ART.AGT-184) – 1/30 pcs.

*Quantity of pcs. in a bulk package.

Storage:

Store in dry, well-ventilated areas, away from heat sources, ignition points and direct sunlight.

Technical support:

AG TermoPasty provides technical support, answering questions about the technical specifications and applications of our products. Please contact us via email at info@termopasty.pl.

Note:

The data presented in this document reflects our current level of knowledge and describes the typical properties and applications of the product. However, the responsibility for determining its suitability for specific applications lies with the user. AG TermoPasty is not liable for the results of product use, as the conditions of application fall beyond our control.

